

1845 South 48th Street Lincoln, NE 68506 (402) 489-3036

info@fordoldpart.com

Miscellaneous Non-Ford Parts Inventory

	/.toraolapart.com
Trippe Brackets	
Bumper mounted Trippe Driving Light brackets used on 1930s Packard, Auburn, Buick, Cadillac, Pierce Arrow, Duesenberg, Cord and "Big Cars"	
Brackets with Hardware everything to install your lamps	\$225.00
Extra set of Trippe Nuts & Bolts	45.00
Original Knurled Wrench	45.00
Knurled 3/8 Drive socket	25.00